

**BMW R1250R (2019MY)**  
**Screen Adapter Kit Installation.**

This Kit mounts onto the R1250R Accessory Option Screen mount subframe so you will need that too - BMW Reference: 46638382576

Loosely fit the bracket assemblies as shown and fasten using the hardware provided - note the spacer position and M8 fastening bolt shown below.



If you have selected the Baffle option, mount it onto the lower adjustment bolts (shown below with the optional tool-less adjusters).

Note: Ensure a plastic washer is inserted between the baffle and the screen brackets on each side (to prevent metal-to-metal contact).



If you have selected one of our Screens, assemble the new screen screws onto the screen and hold them in place on the back-side using the rubber washers.



Install the screen onto the brackets and fasten using the washers and lock-nuts – only tighten just enough to very lightly compress the rubber washers. Overtightening may cause cracks in the screen.

Note: the rubber washers must be sandwiched between the screen and the brackets.

Install the Accessory Bar (optional) onto the top holes in the screen-side brackets as shown and tighten enough to prevent rotation of the device you are mounting.



You are now ready to take a test ride and find your best setting(s), taking care to familiarise yourself with the bike's new characteristics.

Do not attempt to make adjustments whilst riding.

END